



FEATURE

Easy-to-insert arched blade snapping slit



With the easy-to-insert arched blade snapping slit, the blade can be inserted smoothly and freely.

Durability against repetitive blade snapping



Made of durable long-lasting POM resin with glass fiber.

Slide blade along slope



By sliding down the blade along the slope, the blade can be inserted safely.

Slim size





Small and portable enough to easily fit in a waist bag/bag pocket.

Acetone resistant



Safety Blade Cover




① Lift the red blade cover upward.

② Move it downward until it is securely locked with a snap.

*Be sure to lock the blade cover securely after use.

*If the blade cover is open or not securely locked, the blades may come out through the gap.

How to snap off blade




① Insert the blade into the blade snapping slit with exposing one blade segment only.

② Snap-off the blade by setting it so you snap away from the break lines in the blade.



Compatible with OLFA 18mm, 12.5mm and 9mm

**NOT compatible with OLFA 25 mm, 18 mm: OL, CMP-2*



*We do not guarantee compatibility with discontinued OLFA products, and handles or blades from other manufacturers.

How to snap off blade



- ① Unlock by pushing and spreading the yellow clamps on sides of the main body with your fingers.
 - ② With the red blade cover fully locked, pull the gray blade snapping slit part upward.
 - ③ Be careful when disposing of stored blades.
- *Pull it out with the blade snapping slit up. Otherwise, blades may fly out and cause injury.
*When assembling, be sure to assemble each part correctly and securely.
*Please follow instructions of your local authority for blade disposal methods.
*Be careful when disposing of stored blades.